



TECHNICAL INFORMATION - SERVICING INSTRUCTIONS

PSA

4-027-2228

TEST PROGRAM HISENSE ALL UI

Follow the link to run the test program on different UI:

[4-027-2227](#)