





	Details
显示板	
SW2	Speed control button
SW1	Power button
CN3	Connect the motherboard