



No.	Part Name	Chinese Part Name
10	Front Cover	前壳组件
20	Key board	按键板
30	Speakers assembly	扬声器大组件
40	Wifi broad	WIFI板
50	IR board	遥控板
60	LCD	LCD屏
70	Power board	电源板组件
80	Mainboard	主板大组件
120	Stand unit	底座大组件
130	Back cover	后壳组件